

Installation for scan chain

Contents	
Python Installation	2
Pip and pyusb installation	5
Zadig	8
Test your Installation	11

Note:



Represents mouse click

Yellow highlight represents changes made

Python Installation:


If you **already have python installed** then:


No need to follow this section but you should have path to python set in system variable. To test it type **python** or **python3** or **py** in windows command prompt. It should open python command line. If command **python** or **python3** works for you, replace **py** with **python** or **python3** henceforth in this document in next commands

else:


follow the commands given below:


We will first download python3.9 installer then open the downloaded .exe






Do you want to allow? -> Click Yes






Click on Disable path length limit if the error is seen. And give it permission in Windows Security Dialog Box that appears next.



Type **py** in command prompt to confirm your installation has added to PATH variable. If not, you may have to do it manually, contact your TA.

In Windows command Prompt, Type **py**



```

Command Prompt - py
Microsoft Windows [Version 10.0.19042.746]
(c) 2020 Microsoft Corporation. All rights reserved.

C:\Users\sindh>py
Python 3.9.1 (tags/v3.9.1:1e5d33e, Dec 7 2020, 17:08:21) [MSC v.1927 64 bit (AMD64)] on win32
Type "help", "copyright", "credits" or "license" for more information.
>>>


```

Pip and pyusb installation

If you already have pip installation, you can simply confirm else you need to follow the complete sequence:

In to download pip - Windows Command Prompt-

`curl https://bootstrap.pypa.io/get-pip.py -o get-pip.py`




```

C:\Users\sindh>curl https://bootstrap.pypa.io/get-pip.py -o get-pip.py
% Total    % Received % Xferd  Average Speed   Time    Time     Time  Current
           Dload  Upload   Total   Spent    Left  Speed
100 1884k  100 1884k    0     0  314k      0  0:00:06  0:00:06 --:--:-- 277k

```

Type command – **dir** and check get-pip.py appears



```


C:\Users\sindh>dir
Volume in drive C is OS
Volume Serial Number is D661-68E7

Directory of C:\Users\sindh


13-02-2021  12:33    <DIR>          .
13-02-2021  12:33    <DIR>          ..
13-02-2021  12:22    <DIR>          .idlerc
05-11-2020  19:35    <DIR>          3D Objects
05-11-2020  19:35    <DIR>          Contacts
13-02-2021  12:17    <DIR>          Desktop
25-12-2020  19:27    <DIR>          Documents
13-02-2021  11:49    <DIR>          Downloads
05-11-2020  19:35    <DIR>          Favorites
13-02-2021  12:34    1,929,903 get-pip.py
05-11-2020  19:35    <DIR>          Links
05-11-2020  19:35    <DIR>          Music
26-01-2021  22:47    6,029,312 NTUSER.DAT
04-02-2021  12:00    <DIR>          OneDrive
05-11-2020  19:36    <DIR>          Pictures
05-11-2020  19:35    <DIR>          Saved Games
05-11-2020  19:36    <DIR>          Searches
07-11-2020  10:11    <DIR>          Videos
               2 File(s)              7,959,215 bytes
               16 Dir(s)  187,567,542,272 bytes free

```

in Windows – Start panel -



Turn off App Installer python.exe and keep only one python App execution Alias as on, ignore this step if you don't see App Installer python... related Aliases



In Windows Command Prompt-
py get-pip.py

```
C:\Users\sindh>py get-pip.py
Python was not found; run without arguments to install from the Microsoft Store, or disable this shortcut from Settings
> Manage App Execution Aliases.

C:\Users\sindh>py get-pip.py
C:\Users\sindh\AppData\Local\Programs\Python\Python39\lib\site-packages\setuptools\distutils_patch.py:25: UserWarning: Distutils was imported before Setuptools. This usage is discouraged and may exhibit undesirable behaviors or errors. Please use Setuptools' objects directly or at least import Setuptools first.
  warnings.warn(
Collecting pip
  Downloading pip-21.0.1-py3-none-any.whl (1.5 MB)
    | 1.5 MB 261 kB/s
Collecting wheel
  Downloading wheel-0.36.2-py2.py3-none-any.whl (35 kB)
Installing collected packages: wheel, pip
  WARNING: The script wheel.exe is installed in 'C:\Users\sindh\AppData\Local\Programs\Python\Python39\Scripts' which is not on PATH.
  Consider adding this directory to PATH or, if you prefer to suppress this warning, use --no-warn-script-location.
  Attempting uninstall: pip
    Found existing installation: pip 20.2.3
    Uninstalling pip-20.2.3:
      Successfully uninstalled pip-20.2.3
  WARNING: The scripts pip.exe, pip3.9.exe and pip3.exe are installed in 'C:\Users\sindh\AppData\Local\Programs\Python\Python39\Scripts' which is not on PATH.
  Consider adding this directory to PATH or, if you prefer to suppress this warning, use --no-warn-script-location.
Successfully installed pip-21.0.1 wheel-0.36.2
```

To check pip installation -
py -m pip --version

```
C:\Users\sindh>py -m pip --version
pip 21.0.1 from C:\Users\sindh\AppData\Local\Programs\Python\Python39\lib\site-packages\pip (python 3.9)
```



To install **pyusb** -
in Windows command Prompt-
py -m pip install pyusb

```
C:\Users\sindh>py -m pip install pyusb
Collecting pyusb
  Downloading pyusb-1.1.1-py3-none-any.whl (58 kB)
    | 58 kB 718 kB/s
Installing collected packages: pyusb
Successfully installed pyusb-1.1.1
```


Zadig

After connecting Tiva C board to PC via Device USB connector on Tiva-C and keep it connected for next parts also. Note the position of slide switch in TivaC photograph

To – PC
USB port




Download Zadig




Open

note: Tiva-C is connected to PC and open zadig-2.5.exe that you downloaded, select Generic Bulk Device and libusb-win(v1.2.6.0) and click Install Driver



Test your Installation

After connecting Tiva-C to PC (don't make any other connections other than USB of Tiva_C Device to PC as we are just testing our installation) First download scan chain folder from Teams or moodle




In scan chain folder shared with you download and extract the folder in some location in your PC Here, there should be **no spaces** in the path to this directory.

If the folder that you extracted in previous step is in other drive than C-Drive then first enter Drive name in command prompt e.g Drive D->

```
C:\Users\sindh>D:
```

```
D:\>
```

Copy the location of extracted scan-chain folder and in command prompt enter command - chdir <location of scan_chain_folder> as shown in images below



```
D:\>C:
C:\Users\sindh>chdir C:\Users\sindh\Downloads\ScanChainWindows\ScanChainWindows\
C:\Users\sindh\Downloads\ScanChainWindows\ScanChainWindows>
```

With Tiva C connected to PC – in Windows command prompt, enter command -
py scan.py in.txt out.txt tiva

```
C:\Users\sindh\Downloads\ScanChainWindows\ScanChainWindows>py scan.py in.txt out.txt tiva
Scan chain v3.0
Wadhwani Electronics Laboratory, IIT Bombay
```

If the output appears as shown, **you are ready** for scan chain experiment, else contact your TA.

```
C:\Users\sindh\Downloads\ScanChainWindows\ScanChainWindows>py scan.py in.txt
out.txt tiva
Scan chain v3.0
Wadhwani Electronics Laboratory, IIT Bombay
```

```
Initiating connection with the device..
DEVICE ID 1cbe:0003 on Bus 000 Address 001 =====
bLength      : 0x12 (18 bytes)
bDescriptorType : 0x1 Device
bcdUSB       : 0x110 USB 1.1
bDeviceClass  : 0xff Vendor-specific
bDeviceSubClass : 0x0
bDeviceProtocol : 0x0
```

```

bMaxPacketSize0      : 0x40 (64 bytes)
idVendor              : 0x1cbe
idProduct             : 0x0003
bcdDevice             : 0x100 Device 1.0
iManufacturer        : 0x1 Texas Instruments
iProduct             : 0x2 Generic Bulk Device
iSerialNumber        : 0x3 12345678
bNumConfigurations    : 0x1
CONFIGURATION 1: 500 mA =====
bLength              : 0x9 (9 bytes)
bDescriptorType      : 0x2 Configuration
wTotalLength         : 0x20 (32 bytes)
bNumInterfaces       : 0x1
bConfigurationValue  : 0x1
iConfiguration       : 0x5 Bulk Data Configuration
bmAttributes         : 0xc0 Self Powered
bMaxPower            : 0xfa (500 mA)
INTERFACE 0: Vendor Specific =====
bLength              : 0x9 (9 bytes)
bDescriptorType      : 0x4 Interface
bInterfaceNumber     : 0x0
bAlternateSetting    : 0x0
bNumEndpoints       : 0x2
bInterfaceClass      : 0xff Vendor Specific
bInterfaceSubClass   : 0x0
bInterfaceProtocol   : 0x0
iInterface           : 0x4 Bulk Data Interface
ENDPOINT 0x81: Bulk IN =====
bLength              : 0x7 (7 bytes)
bDescriptorType      : 0x5 Endpoint
bEndpointAddress     : 0x81 IN
bmAttributes         : 0x2 Bulk
wMaxPacketSize       : 0x40 (64 bytes)
bInterval           : 0x0
ENDPOINT 0x1: Bulk OUT =====
bLength              : 0x7 (7 bytes)
bDescriptorType      : 0x5 Endpoint
bEndpointAddress     : 0x1 OUT
bmAttributes         : 0x2 Bulk
wMaxPacketSize       : 0x40 (64 bytes)
bInterval           : 0x0
Device found..
Please wait, Setting it's configuration...
Done !
Claiming interface..
Connection established.

Ready to roll!!!

#----- Command - 1 : SDR 3 TDI(0) 2 TDO(0) MASK(F) -----#

Successfully entered the input..

#----- Command - 2 : RUNTEST 1 MSEC -----#

```

```
#----- Command - 3 : SDR 3 TDI(7) 2 TDO(3) MASK(F) -----#
```

```
Successfully entered the input..
```

```
Sampling out data..
```

```
F
```

```
Output Comparison : Success
```

```
#----- Command - 4 : RUNTEST 1 MSEC -----#
```

```
Sampling out data..
```

```
F
```

```
Output Comparison : Failure
```

```
NOT OK. Check Output file for incorrect outputs.
```

```
Transaction Complete.
```